

**HONEYCOMB
CORE**

TDM
MAKERS OF FINE DOORS



PRE-PRIMED, HANG & PAINT. NO OTHER PREPARATION REQUIRED.

This TDM Deep Moulded Interior Door has been designed to reduce finishing to a minimum. Every door in the range is factory pre-primed, ready for you to simply add a gloss or semi-gloss finish.

Just follow these simple rules to achieve a professional looking finish which, with reasonable care and a minimum of maintenance, will look good for years to come.

Prior to hanging allow the door sufficient time to reach an equilibrium moisture content compatible with the average for the building, this typically takes up to 48 hours.

It is always advisable to paint immediately after hanging.

When painting, special care should be taken to achieve the best results. Use only quality finishing products and follow the paint manufacturers' instructions at all times.

PAINTING INSTRUCTIONS

Before painting make sure the doors are clean and dry. Any handling marks should be removed with a fine grade of sandpaper (150 grit) and dusted off with a soft brush or rag.

Next, paint the edges of the door and touch-up, with a good quality white acrylic primer/undercoat, any

areas where the surface primer may be damaged. Apply a coat of good quality undercoat to the remainder of the door.

When this coat is fully dry, apply two coats of good quality gloss or semi-gloss paint, sanding down between each coat.

TOP TIP

Why limit yourself to white? TDM Deep Moulded doors are pre-primed in white to allow you to colour the door to suit your application. Your local paint merchant will be able to show you an almost infinite range of colours and finishes to match your door to the colour scheme of your choice.

Be creative - the only limitation is your own imagination!



**TDM moulded doors are manufactured using
HONEYCOMB EXPANDED PAPER in the core for added strength.**



All TDM doors are manufactured in accordance with the SABS Standard Specification for Wooden Doors - SABS 545-1989. This specification lays down a rigid set of performance criteria against which each door is tested and approved before the SABS mark can be applied to the door.

